

PARTS LIST

BL4800


CONTENTS

FRAME, BLOWER	1 ~	2
ENGINE	3 ~	4
CARBURETOR, RECOIL STARTER...	5 ~	6
ACCESSORIES		7

1996. 07.



Model BL4800 Frame & Blower




Model BL4800 Frame & Blower

Ref. No.	Part No.	Description	Q'ty	Remarks
1	395666	BL4800	1	
2	118282	Engine	1	TE048M-BG24
3	092512	Bolt	4	M6X45
4	108472	Muffler Cover	1	
5	092018	Screw	2	M5X15
6	114433	Fan Case (Engine side)	1	
7	114434	Fan Case (Frame side)	1	
8	089578	Tapping Screw	12	M5X28
9	103550	Clamp	1	
10	107696	Fan	1	
11	092503	Bolt	3	M6X25
12	105660	Pipe	1	
13	011367	O-Ring	1	V70
14	100808	Rubber Joint	1	
15	086062	Tapping Screw	4	M5X14
16	113816	Handle	1	
17	114195	Nut	4	M5
18	113818	Plate	2	
19	113819	Packing, Lower	1	
20	113910	Packing, Upper	1	
21	092052	Screw	4	M5X18
22	118283	Label	1	BL4800
23	118230	Label	1	
24	117601	Wire	1	
25	117622	Throttle Lever Assembly	1	Includes 26~41
26	107126	Arm	1	
27	107127	Lever	1	
28	107221	Spring	1	
29	106498	Ball	1	5/32 (ø3.9688)
30	107129	Stay	1	
31	019001	Tapping Screw	2	M4X10
32	081457	Screw	1	M6X25
33	081031	Nut	1	M6
34	107136	Collar	1	ø6.6Xø8X15L
35	012502	Spring Washer	1	M6
36	012488	Washer	1	M6
37	115605	Flange	1	
38	115612	Knob Bolt	1	M8X35
39	107581	Nut	1	M8
40	065842	Cotter Pin	1	2X15L

Ref. No.	Part No.	Description	Q'ty	Remarks
41	117623	Switch	1	
42	081456	Screw	2	M6X20
43	013754	Washer	4	M6
44	112509	Nut	2	M6
45	118558	Backpack Frame	1	
46	114454	Buffer	2	
47	026223	Buffer	2	
48	109704	Nut	6	M6
49	114848	Cusion Pad	1	
50	100749	Fastener	4	
51	116691	Shoulder Strap Assembly	2	
52	083445	Screw	2	M6X16
53	081414	Screw	2	M5X14
54	015479	Washer	2	ø5.3Xø16Xt1.6
55	118285	Fuel Tank Assembly	1	Includes 56~68
56	118275	Fuel Tank	1	
57	118287	Tank Cap Assembly	1	Include 58
58	944268	Breather	1	
59	998419	Fuel Filter Assembly	1	Includes 60~66
60	944602	Clamp	2	
61	944843	Clamp	1	
62	944842	Joint	1	
63	944844	Tube	1	
64	944841	Washer	1	
65	573070	Fuel Filter	1	
66	573069	Weight	1	
67	114624	Tube, Fuel Return	1	ø8Xø12X75L
68	043832	Clamp	2	

Model BL4800 Engine




Model BL4800 Engine

Ref. No.	Part No.	Description	Q'ty	Remarks
1	118282	Engine	1	TE048M-BG24
2	570241	Cylinder	1	New gasket required
3	579536	Gasket	1	
4	943288	Bolt	4	
5	591093	Shroud	1	
6	570254	Bolt	2	M5X10
7	584743	Gasket	1	
8	621454	Muffler	1	Includes 9,10
9	621455	Spark Arrester	1	
10	621456	Bolt	1	
11	577390	Bolt	2	M6X65
12	943276	Screw	1	
13	998403	Gasket	2	
14	998404	Insulator	1	New gasket required
15	570244	Piston	1	
16	943304	Piston Ring Set	1	
17	944769	Piston Pin	1	
18	943307	Clip, Piston Pin	2	
19	570245	Crankshaft Assembly	1	Include 20
20	597289	Needle Bearing	1	
21	570246	Crankcase	1	
22	570247	Crankcase	1	
23	943349	Dowel Pin	2	
24	570248	Gasket	1	
25	071320	Oil Seal	2	
26	071386	Bearing	2	6202
27	597285	Shim (t0.1)	AR	
27	597286	Shim (t0.2)	AR	
27	597287	Shim (t0.4)	AR	
27	597288	Shim (t0.6)	AR	
28	998409	Key	1	
29	944728	Screw	4	M6X30
30	944619	Screw	1	M6X8
31	943893	Gasket	1	
32	597291	Flywheel	1	
33	597262	Ignition Coil	1	
34	597293	Grommet	1	
35	998411	Tube	1	
36	943457	Bolt	2	M5X20
37	998410	Nut	1	

Ref. No.	Part No.	Description	Q'ty	Remarks
38	943924	Washer	1	
39	597263	Lead Wire	1	
40	071344	Washer	2	
41	998414	Starter Pawl Assembly	1	Includes 42~44
42	572938	Pawl	1	
43	998416	Return Spring	1	
44	944226	E-Ring	1	
45	998417	Nut	1	
46	117607	Throttle Cable	1	
47	943274	Screw	2	
48	597310	Gasket	1	
49	998389	Air Filter Case	1	
50	998392	Air Filter Element	1	
51	998391	Air Filter Element	1	
52	998393	Screen	1	
53	998390	Air Filter Cover	1	
54	944125	Screw	3	M4X12
55	998405	Tube	1	
56	621453	Spark Plug	1	
57	943773	Spark Plug Cap	1	
58	943771	Terminal	1	
59	570252	Cover	1	

Model BL4800 Carburetor & Recoil Starter




Model BL4800 Carburetor & Recoil Starter

Ref. No.	Part No.	Description	Q'ty	Remarks
1	621457	Carburetor Assembly	1	Includes 2-30
2	944642	Cap	1	
3	944349	Adjuster	1	
4	944348	Nut	1	
5	943914	Screw	2	
6	944347	Cap	1	
7	597296	Gasket	1	
8	998420	Spring	1	
9	597303	Spring Retainer	1	
10	071145	Snap Ring	1	
11	621458	Needle Jet	1	
12	943325	Throttle Valve	1	
13	944689	Choke Plate	1	
14	944102	Spring Washer	1	
15	591564	Nut	1	
16	998421	Lever	1	
17	998422	Jet Needle	1	
18	570255	Main Jet	1	
19	998424	Gasket	1	
20	943621	Screw	4	
21	943750	Pump Cover	1	
22	570256	Pump Diaphragm	1	
23	943751	Gasket	1	
24	998426	Spring	2	
25	998427	Float Chamber	1	
26	998428	Screw	2	
27	998429	Wire	1	
28	998430	Screw	2	
29	578508	Plate	1	
30	998432	Primer Bulb	1	
31	998413	Recoil Starter Assembly	1	Includes 32-41
32	944502	Plate	1	
33	998437	Grip	1	
34	998438	Rope Guide	1	
35	998439	Recoil Case	1	
36	998440	Shield	1	
37	998435	Spring	1	
38	998436	Rope	1	
39	998434	Reel	1	
40	944801	Screw	1	
41	998433	Washer	1	
42	943275	Screw	4	
43	573648	Label	1	



Model BL4800 Accessories



Ref. No.	Part No.	Description	Q'ty	Remarks
1	105668	Flexible Pipe	1	
2	106721	Swivel Pipe Assembly	1	
3	107149	Straight Pipe	1	600L
4	107483	Decal	1	
5	106725	Bent Pipe	1	
6	106726	Fan-Blow Head	1	
7	100823	Wire Clamp, Large	1	#95 (3.75 in.)
8	100753	Wire Clamp, Small	1	#78 (3.0 in.)
9	118279	Instruction Manual	1	BL4000/BL4800