

S.NO	SPARE PART LIST
SMYP201	BODY
SMYP202	CONICAL EDGE
SMYP203	CONICAL EDGE NUT
SMYP204	CONICAL EDGE CONNECTION KIT
SMYP205	MAIN COUPLING
SMYP206	MAIN COUPLING BUSHING
SMYP207	INNER COUPLING NUT
SMYP208	MIL MAIN CROME SHAFT
SMYP209	MAIN CROME SHAFT BUSHING
SMYP210	TRUNNION (BALL LEVER)
SMYP211	HOOK WEDGE
SMYP212	BALL LEVER
SMYP213	BALL LEVER PIN AND RING
SMYP214	CHUCK
SMYP215	CHUCK BALL
SMYP217	BEVEL DRIVE
SMYP218	BEVEL DRIVE BALL
SMYP219	BEVEL DRIVE BUSHING
SMYP220	BEVEL DRIVE COVER
SMYP221	BEVEL DRIVE FELT GASKET
SMYP222	DRUM
SMYP223	GLOVE
SMYP224	GLOVE KEY
SMYP225	GLOVE SPRING
SMYP226	GLOVE RUBBER BUSHING
SMYP227	COUPLING ADJUSTMENT NUT
SMYP228	HEAD NUT
SMYP229	HEAD FELT GASKET
SMYP230	THROTTLE HOLDER
SMYP231	GEAR WHEEL COVER
SMYP232	SIDE COVER
SMYP233	FOOTAGE
SMYP234	HAND KEEPER
SMYP235	THROTTLE TRIGGER
SMYP236	THROTTLE WIRE
SMYP237	HANGER
SMYP238	HANGER HOOK
SMYP239	HOOK
SMYP240	HOOK RUBBER
SMYP241	TUBE
SMYP242	TUBE END
SMYP243	32 mm ADJUSTABLE WRENCH
SMYP244	20 mm ADJUSTABLE WRENCH
SMYP245	SPARK PLUG WRENCH
SMYP246	WRENCH BAG
SMYP247	THROTTLE HOLDER TUBE