


2500CX (3500CX/3800CX) 分解图



2500CX EXPLOSIVE SPARE PARTS LIST

NO.	零件代号/Part No.	零件名称	Part Name	Part Model	数量/Qty
1	GB/T16674.1	六角法兰面螺栓M6×7	Hex. Flange Bolt M6X7		3
2	XQ168F-091000	手拉盘	Recoil starter	168F	1
3	GB/T16674.1	六角法兰面螺栓M6×12	Hex. Flange Bolt M6X12		4
4	XQ168F-101000	导风罩	wind housing	168F	1
5	GB/T6177.2	六角法兰面螺母M14×15	Hex. Flange Bolt M14X15		1
6	XQ168F-090001	启动杯	starter cup	168F	1
7	XQ168F-100001	飞轮风叶	Flywheel fan	168F	1
8	XQ168F-081000	飞轮	Flywheel	168F	1
9	GB/T16674.1	六角法兰面螺栓M6×16	Hex. Flange Bolt M6X16		1
10	XQ168F-034000	隔离器	Isolator	168F	1
11	GB/T16674.1	六角法兰面螺栓M6×12	Hex. Flange Bolt M6X12		1
12	XQ168F-100002	飞轮边罩	Flywheel cover	168F	1
13	XQ168F-I-031000	箱体	Crankcase	168F-I	1
14	XQ168F-030005	放油螺栓M10×12	oilout bolt M10X12	168F	2
15	XQ168F-030006	放油螺栓垫圈10×16×1	oilout bolt washer 10x16x1	168F	2
16	XQ168F-070002	调速齿轮轴	Speed governing gear shaft	168F	1
17	GB/T895.2-86	挡圈 6	retainer ring 6		1
18	XQ168F-070008	调速齿轮垫圈6×15×0.5	Speed governing gear washer	168F	1
19	XQ168F-072000	调速齿轮	Speed governing gear	168F	1
20	XQ168F-070008	调速齿轮垫圈6×15×0.5	Speed governing gear washer	168F	1
21	XQ168F-070002	滑套	sliding sleeve	168F	1
22	XQ168F-070003	摆杆	rocking rod	168F	1
23	GB9/T7.1-02	平垫圈φ6	flat wahser φ6		1
24	XQ168F-070007	复位拉簧	RST pullback spring	168F	1
25	XQ168F-070005	调速拉杆	Speed governing Rod	168F	1
26	XQ168F-070004	调速臂	Speed governing Arm	168F	1
27	XQ168F-070011	方头螺栓	Coach bolt	168F	1
28	XQ168F-070010	弹性销	Spring pin	168F	1
29	GB9/T7.1-02	平垫圈φ6	flat wahser φ6		1
30	XQ168F-070006	调速拉簧	Speed governing spring	168F	1
31	GB6177.1	六角法兰面螺母M6	Hex. Flange Bolt M6		1
32	GB/T16674.1	六角法兰面螺栓M6×12	Hex. Flange Bolt M6X12		2
33	XQ2500CX-071000	调速座	Speed governing base	2500CX	1
34	XQ168F-082000	点火器	C.D.I.	168F	1
35	GB/T16674.1	螺栓 M6×25	Bolt M6x25		2
36	XQ168F-033000	机油报警器	Oil Sensation	168F	1
37	XQ168F-032000	油封41.25×25×6	Oil Seal 41.25×25×6	168F	1
38	GB276-94	轴承 6205	Bearing 6205		1
39	XQ168F-041002	连杆大头盖	Connecting Rod cover	168F	1
40	XQ168F-041003	连杆螺栓	Connecting rod bolt	168F	2
41	GB/T1099-79	半圆键 5×5.5×25	woodruff key 5×5.5×25		1
42	XQ168F-I-051000	曲轴	crankshaft	168F-I	1

43	XQ168F-030003	曲轴箱垫片	crankcase gasket	168F	1
44	XQ168F-030004	定位销 φ18×14	Locating Pin φ18×14	168F	2
45	GB276-94	轴承 6205	Bearing 6205		1
46	XQ168F-032000	油封41.25×25×6	Oil Seal 41.25×25×6	168F	1
47	XQ168F-030002	箱盖	crankcase cover	168F	1
48	XQ168F-030001	机油尺	Oil rule	168F	1
49	GB/T16674.1	六角法兰面螺栓M8×33	Hex. Flange Bolt M8X33		6
50	XQ168F-I-061000	凸轮轴	camshaft	168F-I	1
51	XQ168F-100003	引风板	wind plate	168F	1
52	GB/T16674.1	六角法兰面螺栓M6×12	Hex. Flange Bolt M6X12		2
53	GB899-88	双头螺栓 AM8×20	Stud AM8×20		2
54	GB/T16674.1	六角法兰面螺栓M6×12	Hex. Flange Bolt M6X12		4
55	XQ168F-022000	呼吸器	Cylinder Head Cover	168F	1
56	XQ2500CX-020004	废气管	Exhaust pipe	2500CX	1
57	XQ168F-020003	呼吸器垫片	Cylinder Head Cover gasket	168F	1
58	XQ168F-060008	摇臂锁紧螺母	rocker arm locknut	168F	2
59	XQ168F-060007	气门调整螺母	gas distribution adjustment	168F	2
60	XQ168F-060006	摇臂	Rocker arm	168F	2
61	XQ168F-060009	摇臂螺栓	Rocker arm bolt	168F	2
62	XQ168F-060005	导向板	guide plate	168F	1
63	F6RTC	火花塞	spark plug		1
64	XQ168F-060010	进气门弹簧座	Intake valve spring seat	168F	1
65	XQ168F-060011	排气门弹簧座	Exhaust valve spring seat	168F	1
66	XQ168F-060012	顶帽	hood	168F	1
67	XQ168F-060013	气门弹簧	valve spring	168F	2
68	XQ168F-062000	气门油封	valve oil seal	168F	1
69	GB/T16674.1	六角法兰面螺栓M8×55	Hex. Flange Bolt M8X55		4
70	XQ168F-I-021000	缸头	Cylinder head	168F-I	1
71	XQ168F-020001	定位销 φ10×14	Locating Pin φ10×14	168F	2
72	XQ168F-060003	进气门	Intake valve	168F	1
73	XQ168F-060004	排气门	Exhaust valve	168F	1
74	XQ168F-I-020002	缸头垫片	Cylinder Head gasket	168F-I	1
75	XQ168F-040002	第一道气环	Piston ring 01	168F	1
76	XQ168F-040003	第二道气环	Piston ring 02	168F	1
77	XQ168F-040004	片环	bush ring	168F	2
78	XQ168F-040005	衬环	bush ring	168F	1
79	XQ168F-I-040001	活塞	Piston	168F-I	1
80	XQ168F-040007	活塞销挡圈 19	Piston Pin check ring	168F	2
81	XQ168F-040006	活塞销	Piston Pin	168F	1
82	XQ168F-060002	推杆	push rod	168F	2
83	XQ168F-I-060001	挺柱	tappet	168F-I	2
84	XQ168F-041001	连杆体	Connecting rod	168F	1
85	GB6177.1	六角法兰面螺母M6	Hex. Flange Nut M6		2
86	XQ2500CX-011000	空滤器	Air-cleaner	2500CX	1
87	XQ2500CX-010004	空滤器垫片	Air-cleaner gasket	2500CX	1

88	P18	化油器	Carburator	2500CX	1
89	XQ168F-010003	化油器垫片	Carburator gasket	168F	1
90	XQ168F-010001	隔热板	Heat shield	168F	1
91	XQ2500CX-010002	隔热板垫片	Heat shield gasket	168F	1
92	GB899-88	双头螺栓 AM6×90	stud AM6×113		2
93	XQ2500CX-022000	机架横档	Frame rung	XQ2500C	1
94	GB/T16674.1	六角法兰面螺栓M6×12	Hex. Flange Bolt M6X12		1
95	GB/T16674.1	六角法兰面螺栓M6×12	Hex. Flange Bolt M6X12		8
96	XQ2500CX-020001	圆弧板	Fuel tank cover plate	XQ2500C	2
97	GB6177.1	六角法兰面螺母M8	Hex. Flange Nut M8		12
98	XQ2500CX-023000	前斜减震垫	Front Shock pad	XQ2500C	2
99	GB/T16674.1	六角法兰面螺栓M6×12	Hex. Flange Bolt M6X12		4
100	XQ2500CX-031000	面板组件	Control panel	XQ2500C	1
101	XQ2500CX-021000	机架部件	Frame	XQ2500C	1
102	WP20A-022000	减震脚脚φ27×25	damping foot φ27×25	WP20A	4
103	XQ2500CX-024000	后斜减震垫	Back Shock pad	XQ2500C	2
104	XQ2500CX-012000	电机转子	Altenator rotator	XQ2500C	1
105	XQ2500CX-011000	电机定子	Altenator Stator	XQ2500C	1
106	XQ2500CX-010002	电机后支架	Altenator Rack	XQ2500C	1
107	XQ2500CX-013000	桥锥	Rectifier	XQ2500C	1
108	GB818-85	十字槽盘头螺钉M5×16	Cross bolt M5X12		1
109	XQ2500CX-015000	碳刷	Carbon brush	XQ2500C	1
110	XQ2500CX-014000	调压器	AVR	XQ2500C	1
111	GB818-85	十字槽盘头螺钉M5×12	Cross bolt M5X12		6
112	GB/T16674.1	六角法兰面螺栓M6×12	Hex. Flange Bolt M6X12		1
113	XQ2500CX-052000	消声器支架	Muffler Holder	XQ2500C	1
114	GB/T16674.1	六角法兰面螺栓M8×12	Hex. Flange Bolt M8X12		1
115	GB/T5783-00	六角螺栓M5×20	Hex. Bolt M5X20		2
116	XQ2500CX-010001	接线柱	Binding Post	XQ2500C	1
117	GB97.1-02	垫圈 5	wahser 5		4
118	GB93-87	弹簧垫圈 5	spring washer 5		4
119	GB/T6170-00	六角螺母M5	Hex. Nut M5		4
120	GB/T16674.1	六角法兰面螺栓M6×130	Hex. Flange Bolt M6X130		4
121	GB97.1-02	垫圈 8	washer 8		1
122	GB93-87	弹簧垫圈 8	spring wahser 8		1
123	GB/T16674.1	六角法兰面螺栓M8×205	Hex. Flange Bolt M8X205		1
124	XQ2500CX-010003	电机护罩（电机风罩）	Fan cover	XQ2500C	1
125	GB818-85	十字槽盘头螺钉M5×10	Cross bolt M5X10		2
126	XQ168F-110001	消声器垫片	Muffler gasket	168F	1
127	XQ2500CX-051000	消声器部件	Muffler	XQ2500C	1
128	GB97.1-02	垫圈 8	washer 8		2
129	GB93-87	弹簧垫圈 8	spring washer 8		2
130	GB/T6170.1	六角螺母M8	Hex. Nut mM8		2
131	GB/T16674.1	六角法兰面螺栓M6×12	Hex. Flang bolt M6X12		5
132	XQ2500CX-051001	消声器护罩	Muffler cover	XQ2500C	1

133	XQ2500CX-042000	油箱盖	fuel tank cap	XQ2500C	1
134	XQ2500CX-043000	燃油滤网	fuel strainer	XQ2500C	1
135	GB/T 819.1	开槽沉头螺钉M5×10	Cross bolt M5X10		2
136	XQ2500CX-045000	油位卡尺	Oil lever	XQ2500C	1
137	XQ2500CX-041000	油箱	Fuel tank	XQ2500C	1
138	GB/T16674.1	六角法兰面螺栓M6×18	Hex. Flang bolt M6X18		4
139	XQ2500CX-040003	加大垫片	Washer	XQ2500C	4
140	XQ2500CX-040004	衬套	bush ring	XQ2500C	4
141	XQ2500CX-040005	油箱减震套	fuel tank damping	XQ2500C	4
142	XQ2500CX-044000	燃油开关部件	fuel cock	XQ2500C	1
143	XQ2500CX-040001	燃油管	fuel tube	XQ2500C	1
144	XQ168F-120003	油管卡箍	fuel tube clamp	XQ168F	2